

SOP-MP-031 Foot pad replacement

Procedure: SOP-MP-031

Revision: C

Work record

Work order: WO-QD-5521

Machine: QD-03

Performed on: 2026-05-08

Diagnosis: Foot pad wear beyond limit on leg FL

Procedure

- Power the robot down and place it on the service stand
- Remove the two retaining screws from the foot pad on leg FL
- Fit the new foot pad and torque the screws to 2.5 N.m
- Power up and run the stance self-test

Parts replaced

Part	Removed	Installed
Foot pad FL	FP-0183	FP-0291
Retaining screw set	SCR-KIT-77	SCR-KIT-81
Performed by: M. Alvarez		